

Digital Kitchen Scale Instructions

Instructions:

1. Place kitchen scale on a hard, flat surface, and press the On button.
2. Select your desired measurement unit by pressing the Unit button.
 - a. The scale has four units of measurement: grams, kilograms, ounces, and pounds.
You can switch this at any time.
3. Place your item in the middle of the scale.
4. Tare Function
 - a. The tare function allows you to automatically return the scale to zero at any time, enabling you to subtract the weight of a plate or weigh multiple items in a row.
 - b. Use the tare function by weighing an item normally, and then pressing the On/Off Tare button, which will reset the weight to zero. Then add the next item to the scale and weigh.
2. Do not exceed scale capacity of 11 pounds.
3. Clean scale with a soft, damp cloth and avoid abrasive cleaner. Never sink or submerge in water.

Troubleshooting:

1. If scale displays ERR, place scale on hard, flat surface and then restart it.
2. If scale displays O_LD that means too much weight has been placed on the scale and it is overcapacity.